



1. Positioning of a rubber seal component

A rubber gasket should be exact positioned. At this a line scan sensor type **L-LAS-RL-20-W** is used. The distance to the rubber seal is approximately 55mm and the detecting range about 20mm. The screen shots shows, that a proper positioning of the rubber seal is possible.

