

## Application - News N°450 SPECTRO-3 series

Instruments

## 1. Reflected light color control of coatings on glass plates

The coating of glass plates should be controlled in the reflected light mode. For this purpose a color sensor type SPECTRO-3-SLU-SA-JR in connection with an external light source type SI-SLU-DIF-16 and a holder type MOUNT-SLU-20°/20°-100 will be used. At this, the glass plate is placed at a distance of approximately 100mm to the transmitter and the receiver part. The coating can be proper detected as shown in the screen shots.







